

Plan Your Project

- ▶ Patios, paths driveways and pool surrounds should be at least 80mm but are better at 100mm.
- ▶ Consider using DPM (plastic sheet) for patios, paths and driveways: this eliminates moisture movement which can sometimes contribute to colour variation.
- ▶ Use bar chairs to keep mesh at the right level.
- ▶ Use 665 mesh. 668 is cheaper but has just over half the restraint of 665
- ▶ Plan where cuts are to be made.
- ▶ Don't use polypropylene/plastic fibres as a mesh replacement. It is our belief that olypropylene fibres help only with early age cracking reduction and are not suitable to replace mesh.

